


Neck & Shoulder Massager




USER MANUAL

Please read the user manual carefully prior to use

Safety Precautions

01. This product is for personal use only and is not a medical instrument or for commercial activities.
02. To avoid wire breakage or poor contact, do not pull the power cord. When unplugging, hold onto the plug and then unplug it.
03. Avoid operating the product under blankets or pillows and allow for proper heat dissipation to prevent overheating, which could lead to fire, electric shock, or injury.
04. Do not use the product in areas with corrosive products or oxygen administration.
05. Do not use the product in high humidity or high temperature environments that may cause electric shock or other safety hazards.
06. Supervision is required when children or individuals lacking knowledge use the product.
07. Use the product only for its intended purpose as described in the manual.
08. Do not use the product if it has a damaged cord or plug, is not working properly, has been dropped or damaged, or has come into contact with water.
09. Immediately stop using the product if you experience discomfort or severe pain during use.
10. Stop using the product if it is not working properly.
11. Do not use the product while driving and obey driving laws for safety.
12. Consult a doctor before using this product if you have any of the following conditions:
 - During pregnancy, menstruation, or shortly after delivery
 - Implanted medical electronic devices, such as a cardiac pacemaker
 - Blood circulation disorders or thrombosis
 - Osteoporosis
 - Skin infections
 - Heart disease patients
 - Wounds or surface diseases on the body
 - People who are sensitive to heat
 - Physical disabilities, sensory or neurological deficits, or lack of experience and common sense (including children with mental illness or physical paralysis)

Massage Areas



Shoulder



Neck



Thigh



Back




Waist



Calf

Package List



Shoulder Massager





User Manual



Charging Cable

Operation Guide



Power button:

Press and hold for 2 seconds to turn on the kneading and heating functions, which start in the slow gear mode (green light on). Press and hold for 2 seconds to turn off.

Mode button:

In the power-on state, short press to switch to the pinch kneading mode. Press again to switch back to normal mode.

Heating button:

Short press to turn on/off the heating function. When the heating is on, the indicator turns green. It turns off when the heating off.

Speed button:

In the power-on state, the slow gear mode is default. Short press to switch to fast gear and then press again to switch back to slow gear.

Specifications

Product Name	Neck & Shoulder Massager
Model	HXR-E080
Battery Capacity	2200 mAh
Charging Time	3.5-4 Hours
Running time	80-100 mins
Power	10W
Charging	5V
Timer	10Mins
Package Size	L9.8*W5.3*H6.3inch
Package weight	1.38kg/3.04lb

Product Cleaning and Maintenance

01. To clean the product, first turn it off.
02. The zippered fabric cover can be removed, wash it either by hand or in a washing machine. Allow it to air dry completely.
03. Use a soft, dry cloth to wipe the surface of the product and control panel.
04. Do not use corrosive detergents as they can damage the product or cause the color to fade.



Contact Us

If you need any assistance or support, please contact us via amazon or our service mail:

We offer a 1-year warranty for products. If your neck & shoulder massager malfunctions within this period, we'll replace it for free. Contact us by email for assistance.